








## LIGHTING THE ECO-BURNER

| STEP | INSTRUCTIONS   | VISUAL  |
|------|--|---|
| 1    | Collect Eco-burners from the storage area and take to the buffet. An upside-down Eco-burner has been filled and is ready for use.  |    |
| 2    | Place the Eco-burner on a level surface with the burner head at the top.   |    |
| 3    | Turn the control dial fully anti-clockwise. You will hear the fuel flow.   |   |
| 4    | Carefully light the burner head while in a well ventilated area. The Eco-burner is ready to use when the burner head glows orange. |  |
| 5    | Turn the control dial clockwise to reduce the heat output.<br><u>Note</u> – It is unlikely that you will need to run at maximum    |  |
| 6    | Place the Eco-burner under the chafing dish. Ensure water level in the dish is minimum 2cm. Never allow the water to run dry.      |  |
| 7    | <b>To TURN OFF the Eco-burner</b> – rotate the Control Dial fully clockwise.   |  |